RMF – High Availability PTZ Presets in the Smart Client

Vega Systems Inc.

03/14/2023
https://www.vega25.com/rmf

Step 1: **Login** into **Parent Management Server** as domain user with admin privileges.(Federated Deployments)

Login into **Management Server** as an admin user. (Non-Federated Deployments)

Note: RMF should be configured before proceeding with this workflow. Applicable for PTZ cameras only.

Step 2: Click the **preset button** as shown above.

Note: Applicable for PTZ cameras only.

**Step 3**: Click **Manage PTZ presets** option.

Add PTZ Preset

Step 1: Move the PTZ to the needed view. Click **Add new PTZ preset**.

6

Step 2: Provide a **PTZ preset name**. Click **OK**.

**Step 3**: Added PTZ Preset is available in the **Camera PTZ presets list**.

Update PTZ Preset

Step 1: **Select a PTZ preset** from the Camera PTZ presets list**. Move to the desired position.** Click **Update the selected PTZ preset** button to update the position**.**

# Delete PTZ Preset

Step 1: **Select a PTZ preset** from the Camera PTZ presets list.
Click **Delete PTZ preset** button.

**Step 2**: The deleted **PTZ preset is removed** from the list..

Move between PTZ presets

**Step 1**: Click the buttons (highlighted above) to **move across the PTZ presets** in the list.

Saving and verifying the PTZ presets

Step 1: Click the **Close** button.

Step 2: **Re-login t**o the **Smart Client** to get the updated preset list. Click **OK.**

Step 3: **Login** into **Parent Management Server** using domain user credentials. (Federated Deployments)
Login into **Management Server**. (Federated Deployments)

Step 4: Click the **Presets** button, as shown above. The list of PTZ presets added is shown in the list.

Note: The camera is streaming from the parent (primary) recording server.

Step 5: The **list of PTZ presets** added is shown even when the streaming has switched to the **child (secondary) recording server**.

**PTZ Preset - Role Access
(Admin Scope)**

Step 1: Open the **Management Client**.

Note: Run as administrator

Step 2: **Login** into the **Parent Management Server** as a domain user with admin privileges. (Federated Deployments)

Login into **Management Server** as a user with admin privileges (Non-Federated Deployments)

Step 3: Goto **Security → Roles**. **Add a new role or select an existing role**.

Step 4: Select the **PTZ tab** from the bottom toolbar.

Select a **PTZ camera** or the **camera group** which consists of a PTZ camera.

Step 5: Select the **Activate PTZ presets or patrolling profiles**.
Without selecting this option, a user cannot consume or traverse the
PTZ presets created by the admin user.